


| REVISION HISTORY | | | |
|------------------|-------------|------|----------|
| REV | DESCRIPTION | DATE | APPROVED |
| | | | |



Furnace 1. Basic layout
 Furnace 2. Upflow & trouble-shooting
 Furnace 3. Downflow
 Furnace 4. Controls
 Furnace 5. variations on controls
 Furnace 6.
 Furnace 7.
 Furnace 8.

FOR INFORMATION ONLY
 Contingent on equipment manufacturers WARNINGS..
 cautions, instructions and requirements. READ THOSE
 CAREFULLY. This sketch if for general orientation ONLY.

© Phil from his other publications. ALUMALITE on JA
 Unlimited use granted to JustAnswers.com

FURNACE TROUBLE SHOOTING #2

Generic diagram, for orientation and basic principles reference only. Not specific equipment.